



700 Pine Ridge Road Golden CO 80403 Tel (303) 278 8287 1(888) 4X4 SLEE Fax (303) 278 7182

## Slee Off-Road 1993-97 Land Cruiser / LX450 Toyota OE Center Diff Lock Switch - Installation Instructions

Qty	Part Included	Suggested Tools
1	CDL Switch	Small Flat Blade Screwdriver
		Phillips Head Screwdriver

Thank you for your purchase from Slee Off-Road! If you should have any questions or concerns, please don't hesitate to contact us immediately at 1 888 4X4 SLEE or at [sales@sleeoffroad.com](mailto:sales@sleeoffroad.com).

Slee Off-Road strives to provide comprehensive installation instructions. However, in some circumstances minor inconsistencies may be encountered with instructions and or provided parts. If you encounter such an inconsistency, please notify us, as your input is important. Slee Off-Road guarantees all parts free from defects for one year from the original purchase date.

### Removal of dash trim piece (1993-94 models)

1. Remove the ashtray.
2. Remove the two Phillips screws on either side of the ashtray as well as the one on top of the metal plate.
3. Remove the Phillips screw located under and to the left of the 3 switches along the bottom piece of the dash. (RHD Models)
4. Lower the steering column.
5. Now place one hand at the ashtray opening and the other on the upper right between the stereo and heater controls and pull gently. There should be enough access to find the plug required for the switch installation.

### Removal of dash trim piece (1995-97 models)

1. If your vehicle is fitted with a cup holder, remove it by opening the cup holder and remove the two Phillips screws. If you don't have a cup holder, proceed to step 2.
2. Insert a small flat blade screwdriver under the locking tabs located on the top edge of the little "cubby hole" that is located above the radio.
3. Bend the tab down gently and pull.
4. Repeat Step 3 with other tab. Once both tabs are released the trim piece can be removed.
5. Remove the two Phillips screws on either side of the opening.
6. Remove the ashtray.
7. Remove the two screws on either side of the ashtray opening and remove the metal bracket.
8. Grab hold of the center 'ribs' of the trim piece and pull gently. The trim piece should un-clip. It is attached with push in plugs. Use caution and don't apply excessive force.

**Slee Off-Road 1993-97 Land Cruiser / LX450 Toyota OE Center Diff Lock Switch -**  
Installation Instructions 2 of 2

**Installation of the CDL switch (1993-97)**

1. Remove one of the switch blanks and insert the switch (the most common location for the switch is the top left most position).
2. Locate the unused terminator on the wiring harness. It can be located behind the radio or above the A/C controls. To identify it, it will be a white female plug with a terminating male plug inserted into it. It might be wrapped in foam with a green/silver jumper wire (see photo).
3. Remove the terminating plug and feed the connector end through the top slot on the dash and then connect to the switch you've installed in Step 1 of this paragraph.
4. Re-install the trim piece in the reverse order removed.
5. Verify operation by pressing the switch, the ABS and Center Diff lights will light up in the gauge cluster.



Diff lock switch harness with terminating plug installed **(Step 2)**

Thank you for your purchase from Slee Off-Road! Visit us at [sleeoffroad.com](http://sleeoffroad.com) or email us at [sales@sleeoffroad.com](mailto:sales@sleeoffroad.com). Follow us on Facebook and Instagram!

