





700 Pine Ridge Road Golden CO 80403 **Tel** (303) 278 8287 1(888) 4X4 SLEE **Fax** (303) 278 7182

Slee Off-Road – ARB 2008+ Land Cruiser Skid Plate Addendum (54415100) – Preliminary Installation Instructions

Qty	Parts Included	Tools
4	1/2" Washer	Please Reference ARB "Required Tools" on Page 2 of 12 Of ARB Fitting Instructions
4	1/2" Lock Washer	
4	M12 x 1.5 Nuts	

Thank you for your purchase from Slee Off-Road! If you should you have any questions or concerns, please do not hesitate to contact us immediately at 1 888 4X4 SLEE or at sales@sleeoffroad.com.

Slee Off-Road strives to provide comprehensive installation instructions. However, in some circumstances minor inconsistencies may be encountered with instructions and or provided parts. If you encounter such an inconsistency, please notify us, as your input is important. Slee Off-Road guarantees all parts free from defects for one year from the original purchase date. Slee Off-Road and Slee & Co under no circumstances will be held liable for any damages or injuries to the users of this product(s) and or their equipment as a result of the use of this information or parts obtained from Slee Off Road.

<p>1. In reference to step 19.</p> <p>The “nuts” aren’t supplied from Toyota.</p>	
<p>2. In reference to step 20.</p> <p>Install the “Transmission Bracket” using the following supplied hardware from Slee Off-Road. Do not tighten hardware.</p> <p>Hardware;</p> <ul style="list-style-type: none">• 4 x 1/2” – Washers• 4 x 1/2” – Lock Washers• 4 x M12 x 1.5 Nuts	
<p>3. In Reference to Step 24.</p> <p>Push the “Transmission Bracket” down as far as possible to provide clearance to the transfer case skid plate.</p>	 <p>Push Transmission bracket down before tightening bolts (Step 24)</p>  <p>Completed installation shown (Step 26)</p>

Thank you for your purchase from Slee Off-Road! Visit us at www.sleeoffroad.com or email us at sales@sleeoffroad.com. Like us on Facebook or visit us on Instagram.