www.plaidwagon.co
kyle@plaidwagon.co
970-712-8568

100 Series Land Cruiser
Leather or Cloth

Seat Back Net Installation Guide

Tools Needed:
-1/8” Allen Wrench
-3/8” Socket or Wrench
-Flush Cut Pliers

Step 1:
Remove seat back panels. This can be done by quickly tugging on a top corner of the panel, or by depressing the clip on the backside. This may be difficult to reach by hand, a thin long flathead screwdriver also does the trick.

Reference the picture below, there’s two plastic clips that grab thin steel wires to hold them in place. The bottom is held in place by two tabs that slip over the seat’s frame.

Step 2:
On the back of each panel, snip off the plastic studs securing the original nets in place. Cut them flush with the washers that hold them tight. Once those are removed you can pull the factory net off the seat back panel.

Step 3:
Clean the front of the seat back panel once the plastic net is removed. Simple Green or

something safe for leather is a good choice.

Step 4:

Put the new frames in position and secure with the provided hardware. The washer and nut go on the back. Tighten hardware by holding the screw in place and turning the nut. Only snug enough to secure the frames to the panel. I like to put the logos towards the outside.

Step 5:

Reinstall the seat back panels by slipping the two bottom tabs over the seat frame and then push each top corner until you hear it click the plastic pieces on to the steel wire. It may take a quick push or two on each side.

That’s it! Any questions at all- reach out to my email.